

### **Installation: Ridge Vent**

1. Hold ridge vent in position and mark the underfelt directly below the ridge vent outlet. Cut and remove the underlay as marked.
2. Bed ridge vents in mortar in a similar manner to the standard ridges. Nail the retaining straps to rafters/ridge board.
3. Complete ridge in normal manner.

If using pipe adaptor, clip felt sleeve and attach CTIC flexitube, after fitting into roof.