

External Edge Corner

A how-to guide to installing an external edge corner.

 Drill pilot hole	Step 1 External corners come with 2 removable tabs.
 Edge plate needs to be flush with the gutter trim	Step 2 Neatly abut trims.
	Step 3 If Edge Trim meets Edge Trim then both tabs need to be removed carefully using a pair of pliers. If Edge Trim meets Gutter Trim then only one tab needs to be removed.
 Polynail	Step 4 Pushing on the corner gently, secure in place using the supplied poly nails or use our corner adhesive.