

Laying Membrane

A how-to guide to laying our Techno EPDM membrane.

	Step 1 Ensure deck is dry and clean.
	Step 2 Position membrane on the roof and allow to relax for 30-45 minutes, slightly longer in colder temperatures.
	Step 3 Fold back one half of the rubber and apply an even coat of water based adhesive to the deck using roller and sleeve. For best results, it is essential that the water based deck adhesive is thoroughly stirred with a paddle stirrer prior to use.
	Step 4 Mate the rubber to the adhesive immediately and use a soft broom to sweep out any air bubbles.



Step 5
Repeat the process for the other side.



Step 6
Thoroughly sweep roof.